





JWI-1200 GRAVITY WALL AIR INLET

Installation Instructions

JWI-1200 PARTS LIST

- Plastic Clip
- Chain
- Insulated Cover
- Styrofoam Baffle
- Air Inlet Protective Screen
- Counterweights (2 per inlet)
- Polyethylene Housing
- Weight Arm



(563) 875-6257 or 1-800-553-4102

www.doublel.com

www.youtube.com/doublelgroup





JWI-2400 GRAVITY WALL AIR INLET

Installation Instructions

JWI-2400 PARTS LIST

- Plastic Clip
- Chain
- Insulated Cover
- Styrofoam Baffle
- Air Inlet Protective Screen
- Counterweights (2 per inlet)
- Polyethylene Housing
- Weight Arm



(563) 875-6257 or 1-800-553-4102

www.doublel.com

www.youtube.com/doublelgroup